Channel Number	Туре	Colour	Power	Description
	1 Sub	Diak - L Diak / sik on -		Sub
	1 Sub x2	Pink = +, Pink w/ silver = -	400w RMS 2ohm, 250w RMS 4 ohm	Sub
	3 Normal power	Grey = +, Grey w/ silver = -	75w RMS 4ohm	Spare
	6 Normal power	Blue = +, Blue w/silver = -	75w RMS 4ohm	RL
	7 Normal power	Brown w/ silver = -, Brown = +	75w RMS 4ohm	FRT
	5 Normal power	Yellow/ silver = +, Yellow = -	75w RMS 4ohm	FLT
	2 High power	Orange = +, Orange w/silver = -	150w RMS 4ohm	RFW
	4 High power	Green = +, Green w/silver = -	150w RMS 4ohm	LFW
	8 Normal power	White = +, White w/ silver = -	75w RMS 4ohm	RR
	9 Normal power	Purple = +, Purple w/ silver = -	75w RMS 4ohm	Center
	Remote Trigger	Blue	12v	Remote OUT trigeer
	10 Preout	RCA Jack		postive
I/A	Power +	Red (Thick Guage)		negative
N/A	Power -	Black (Thick Guage)		RCA preout
Phase can be swapped in DSP		<u> </u>		-